



Steps to install board-base locking piece on 9' see-saw:

First use a drill and 3/16" drill bit to drill 4 pairs of holes where the arrows indicate in the first picture. Then, using the pins provided, attach the locking pieces to the board using the holes you have drilled. You should attach one locking piece on each side of the board. Do not close the lock pieces until you put the board on top of the base.





After putting the board onto the base, you can flip the lock pieces up and use the rest of the pins to lock the board onto the base. Once you have the board secured with the locking pieces, the see-saw board will stay connected with the base. It should look like the next picture when complete.

